

To Enable or Disable the Flashing LED:

Press the "C" Key

C

Press the "key symbol"

⌨

Touch a registered Manager Bypass Key to the key slot until you hear audible feedback



The LED will emit a solid red light



Press "0" to disable the Flashing LED feature

0

or

Press "9" to enable the Flashing LED feature

9

Press the "key symbol"

⌨

A double tone signifies successful programming

